Hose Type VIPER

6VIPER-Y

ID6 - Series: -

SPIR STAR®

Applications

Hydraulics: Torque wrenching

Technical Information

Inner Core: Polyamide (PA)

Pressure Support: Multi layers of high-tensile steel wire and open synthetic

fibers

Outer Cover: Polyurethane (TPU)
Color: Luminous yellow

Temperature: -30°C to +60°C [-22°F to 140°F]



ØID	Ø OD	Workir 	ng Pressure (SF 2,6:1)	Burst Pressure	Bend Radius	Weight	Insert ID
6,1 mm	12,5 mm		700 bar	1.800 bar	80 mm	0,206 kg/m	4,0 mm
0,24 inch	0,49 inch		10.150 psi	26.100 psi	3,15 inch	0,138 lbs/ft	0,16 inch
Part no.	Thread	Material		Dime A	ensions (mm) B C 알		Sleeve
Sleeve VIPER-S	_	Steel		14,4	42		
VIF EN-3	-	Steel		17,7	72	4	8
Discontinue							

			Dimensions (mm)				Insert	
Part no.	Thread	Material	Nut	Α	В	С	암	iliser
Male fitting								
VIPER-M-1/4	I/4"x18NPTF	Steel	-	4	68	14	14	H 23
VIPER-M-3/8	3/8"×18NPTF	Steel	-	4	64	14	17	4 B
Female fitting NPT/NPTF								
VIPER-F-1/4	I/4"x18NPTF	Steel	-	4	67	20	19	

6VIPER-Y

ID6 - Series: -



Part no.	Material	Crimp ring	Dimensions (mm) Ø Length	Bend restrictor
Rubber bend restrictor				
1.9518600	Rubber	QR-HL	34 126	
				- Managa

Part no.	Mesh length (mm)	Overall length (mm)	Breaking strength (kN)	Suitable for SPIR STAR® hose outer diameter (mm)	Hose securing grip
Hose secu	ıring grip shoı	rt version			
9056400	600,00	740,00	10,20	10-15	
Hose secu	ıring grip long	version			
905640L	600,00	990,00	10,20	10-15	

	Accessories combinations					
Without hose protection						
Description	Bend restrictor	Crimp ring	Securing grips			
Bend restrictor	1.9518600	QR-HL	-			
Securing grip	-	-	9056400			
Bend restrictor and securing grip	1.9518600	QR-HL	905640L			

Production related variations of the burst pressure of up to 5 % are possible. Other colors upon request.

The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked. Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center.

The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly may be less.

We reserve our rights for technical changes without notice. Subject to printing errors.

^{*)} Blast-Pro® fittings may only be used for tube cleaning operations inside the tube. They have not been designed for the use outside of tubes.