## Hose Type 20/6PPA®

206PPA4017

SPIR STAR

ID20 - Series: C

#### **Applications**

Hydraulics:	Hydraulic tools (instrumentation packages for gauges, control of service equipment, hydraulic jacks, hydraulic tools)					
Oil and Gas:	Methanol service (oil rigs, distribution panels, umbilicals), jumper/ subsea well control, chemical injection, nitrogen service, Gaseous media handling					



### **Technical Information**

Inner Core:	Polyvinylidenfluoride (PVDF)
Pressure Support:	6 layers of high-tensile steel wire
Outer Cover:	Polyamide (PA)
Color:	Dark green
Temperature:	-20°C to +80°C [-4°F to 176°F]

ØID	Ø OD	Working Pressure		Burst Pressure	rst Pressure Bend Radius		Insert ID
		(SF 3,3:1)	(SF 4,0:1)				
18,8 mm	32,8 mm	1.035 bar	860 bar	3.450 bar	600 mm	2,170 kg/m	13,0 mm
0,74 inch	I,29 inch	15.000 psi	12.500 psi	50.000 psi	23,62 inch	1,454 lbs/ft	0,51 inch

			Sleeve				
Part no.	Thread	Material	А	В	С	r r	Sieeve
Sleeve							
12060111	-	Steel	42,9	72	-	-	8

				Dim	ensions (	mm)		Insert
Part no.	Thread	Material	Nut	А	В	С	4 2	insert
MP fitting								
42060304C	I"xI4UNS LH	Stainless steel	-	13	158	30	-	

Female swive	l with O-Ring							
22060202C	M36x2	Steel	52040201	13	127	-	46	O-Ring
Type M fema	le swivel							
22060644C	I 5/16"x12UN	Stainless steel	52040645	13	107	-	46	AT A A A A A A A A A A A A A A A A A A

# SPIR STAR

## Hose Type 20/6PPA®

					ID20 - Serie	s: C		_		
Part no.	Thread		Material Relief bo		res	Dimension A B		(mm) C	e e	Swivel nut
Swivel nut	t									
52040645	5/16"	xI2UN A	AISI 316Ti	l radial		25,5	31,5	11,5	46	
52040201	M36x2	S	teel	l radial		25,5	38	22	46	
Part no.	Mesh length (mm)	Overall leng (mm)	th Breakin (kN)	g strength	Suitable for SPIR STAR® Fouter diameter (mm)	nose				Hose securing grip
Hose secu	iring grip shor	t version								
9204400	600,00	820,00	35,10		30-40					

206PPA4017

Production related variations of the burst pressure of up to 5 % are possible. Other colors upon request.

Maximum test pressure (1290 bar / 18705 psi).

The safety factors between the burst pressure and the working pressure as well as the test pressure depend on the operating conditions. For gaseous media the outer cover is to be pinpricked.

Regarding the safety factor for gaseous media please contact your local SPIR STAR® assembling center.

The indicated working pressure refers to the hose only. Depending on the used fitting the permitted working pressure of a hose assembly may be less.

We reserve our rights for technical changes without notice. Subject to printing errors.